



**PORTE-PLAQUE « BANDEAU LED »  
TAIL TIDY KIT « LED BAR »**

***Bonneville, Thruxton, Scrambler 790/865cc (2001-2016)***



**Instructions de montage**

- 1 Démontez la selle de la moto (photo 1).
- 2 Débranchez le connecteur du bloc feu-clignotants (photo 2).
- 3 Démontez le garde-boue AR (photos 3 et 4).
- 4 Montez à sa place le passage de roue du kit (avec les vis d'origine, photo 5). Ne pas serrer à ce stade.
- 5 Montez le porte-plaque avec les vis M6 et les écrous du kit. Le bandeau LED se place entre les deux plaques (photos 6, 7 et 8). Ne pas serrer à ce stade.
- 6 Branchez le connecteur du kit en lieu et place du connecteur débranché plus haut. Testez le fonctionnement du feu de position, feu stop et clignotants.
- 7 Serrez les montages ci-dessus.
- 8 Remontez la selle.

***Fitting instructions***

- Remove the seat (photo 1).
- Unplug the connector of the original light unit (photo 2).
- Remove the original mudguard (photos 3 and 4).
- Fit in its place the tail tidy plate (with supplied M6 bolts, photo 5). Do not tighten at this stage.
- Fit the license plate holder to the tail tidy plate (supplied M6 bolts and nuts), placing the LED bar in between the two plates (photo 6, 7 and 8). Do not tighten at this stage.
- Plug the kit's connector into the bike's wiring. Test that all lights work.
- Tighten the fitments left loose above.
- Re-fit the seat.

